

PORTAVALIGIA SPECIFICO - SPECIFIC CASE HOLDER  
 PORTE-VAISE SPECIFIQUE - SPEZIFISCHER KOFFER-TRÄGER  
 PORTA-EQUIPAJE ESPECIFICO - TRANSPORTADOR ESPECIFICO  
**YAMAHA SUPER TENERE' 1200cc**  
 2010

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS - INSTRUCTIONS DE MONTAGE  
 BAUANLEITUNG - INSTRUCCIONES DE MONTAJE - INSTRUÇÕES DE MONTAGEM

**1**



**SUPPORTO**  
 SUPPORT  
 HALTERUNG  
 SOPORTE  
 SUPORTE

**Q.TY n.2(Dx-Sx)**

**2**



**DISTANZIALE Ø18x15mm**  
 Foro Ø8mm, C18L15F8T

**Q.TY n.4**

**3**



**VITE TEF M8x40mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO  
 PARAFUSO

**Q.TY n.4**

**4**



**PIASTRA M5**  
 PLATE  
 PLATINE  
 PLATTE  
 PARRILLA  
 PRATO

**Q.TY n.1**

**5**



**VITE TCEI M6x25mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO  
 PARAFUSO

**Q.TY n.4**

**6**



**RONDELLA Ø6mm**  
 WASHER  
 RONDELLE  
 SCHEIBE  
 ARANDELA  
 ARRUELA

**Q.TY n.4**

**7**



**RONDELLA Ø6x18mm**  
 WASHER  
 RONDELLE  
 SCHEIBE  
 ARANDELA  
 ARRUELA

**Q.TY n.4**

**8**



**COPRIFORO Z621**  
 BOLT CAP  
 CACHE TROU  
 STOPLOCK  
 TAPA AGUJERO  
 BONE

**Q.TY n.6**

**9**



**DADO A.B. M6**  
 BOLT  
 ECROU  
 MUTTER  
 TUERCA  
 PORCA

**Q.TY n.4**

